
 NINGBO DAYE GARDEN MACHINERY CO., LTD.				MODEL	PM 5160 SEHW/ DYM 1678D-3
				PATTERN TITLE	EXPLODED VIEW
DESIGN		STANDARDIZATION		PHASEMARKS	
DRAWING				WEIGHT(g)	
AUDIT				PROPORTION	
CRAFT		APPROVAL		MAPSHEET	
		TOTAL PAGE	PAGE	VERSION	
				DRAWING NO	

PM 5160 SEHW-DYM1678D-3 spare parts list

Model : PM 5160 SEHW-DYM1678D-3
 update : 16.12.2017



Open embedded file for an exploded view.

Nr.	part no.	part description	quantity
1	A26800606201	blade tighten bolt	1
2	2105300001C	dishing washer	1
3	2105200245A	blade support pressing board	1
4	2105200262A	blade	1
5	2105200251A	stamping blade support	1
6	2105300079A	flat key	1
7	21021000020001A	blade support bush	1
8	A26800300502	screw	1
9	2102300109B	driving belt wheel	1
10	2102600036N	triangle belt	1
11	A26800500801	nut	4
12	A26800103701	self-driving screw	12
13	A26800700701	flat ring	2
14	21041001920001B	belt wheel protecting cover	1
15	A26800100501	self-driving screw	22
16	21041002020001A	front panel handle	1
17	21041002980001N	head cover	1
18	21041002990001A	cover plate	1
19	21011001740103N	8"wheel cover	2
20	A26800502801	hex flange locking nut	9
21	2101300065A	bearing	8
22	21011002600001A	wheel ass'y	2
23	21011001460001A	dustproof wheel cover	2
24	A26800706202	wave washer	5
25	21011002030001N	lower support of wheel axle	2
26	A26800611901	hex flange bolt	4
27	21011002020001A	upper support of wheel axle	2
28	A26800500501	hex locking nut	10
29	2101500079C	front wheel axle ass'y	1
30	2109800134A	spring of front wheel axle	2
31	21011001750103N	11"wheel cover	2
32	21011002610001A	wheel ass'y	2
33	2101100081B	wheel gear ring	2

PM 5160 SEHW-DYM1678D-3 spare parts list

Model : PM 5160 SEHW-DYM1678D-3
 update : 16.12.2017



T:\Daye Europe\
 Mowox\exploded
 view drawings

Open embedded file for an exploded view.

Nr.	part no.	part description	quantity
34	21011003730001F	11" dust-proof wheel cover	2
35	2106200820A	connecting rod	1
36	21035001260001A	deck	1
37	A26800502401	hex flange screw	8
38	21061003944017A	height adjustment board	1
39	A26800201901	tooth screw	6
40	2106200128A	wheel axle fixed ring	2
41	A26800900201	open block ring	4
42	2104400013E	left output gear ass'y	1
43	A26800705102	flat washer	2
44	A26800402302	bearing	2
45	2102400152A	bearing sheath	2
46	A26809000102	column pin	2
47	2102300058B	gear box ass'y	1
48	2104400014E	right output gear ass'y	1
49	A26800611201	hex bolt	2
50	2102300154A	position fixing plate	1
51	2103200228A	side-discharge fixing board	1
52	2106200053N	side-discharge position fixing shaft	1
53	A26800800402	spring washer	2
54	A26800201501	tooth screw	2
55	2109800066D	side cover board spring	1
56	21061001790001A	side-discharge cover board	1
57	21041001380001C	side-discharge protecting cover	1
58	21041001160001A	knob pressing board	1
59	2109800022C	spring	1
60	21041001150001A	mulching kit button	1
61	21061000930001A	mulching kit	1
62	A26800203001A	cross pan self-driving screw	1
63	2101500008A	rear wheel axle ass'y	1
64	A26800900301	open block ring	2
65	2109200020A	adjusting washer	1
66	2106200815A	handle ass'y	1

PM 5160 SEHW-DYM1678D-3 spare parts list

Model : PM 5160 SEHW-DYM1678D-3
 update : 16.12.2017



Open embedded file for an exploded view.

Nr.	part no.	part description	quantity
67	A26800303301	screw	2
68	21061002880001A	height adjustment ass'y	1
69	A26800606401	hexagon flange bolt	4
70	21062001660001B	right handle bracket	1
71	2109800072A	right knob spring	1
72	2106300028B	long rod	1
73	2109800071A	left knob spring	1
74	2106600013A	cable protecting sheath	1
75	21062001650001B	left handle bracket	1
76	2106100003A	tube plug	2
77	21061000113201A	curled washer	2
78	21061000020001B	lower handle knob	2
79	A26800502301A	hex nut	2
80	A26800600401	flat head bolt	2
81	21061000013201A	cable clamp	1
82	21061002540001A	cable clamp	1
83	A26800305901	special bolt	1
84	A26800601701	hex bolt	1
85	2109300055A	special bolt	1
86	2103300032A	square washer	3
87	60400106202	engine	1
88	21061003883201N	lower adjustment gear	2
89	21062001800001A	lower handle pole	1
90	2109300058A	self-driving screw	14
91	21061000273201A	locking handle	2
92	2109300063A	column pin	2
93	2109200025A	pressing plate	2
94	2109300026A	locking handle bolt	2
95	21061003843206D	upper adjustment gear	2
96	2109200029B	flat washer	2
97	A26800607701	hex flange bolt	2
98	2106300002A	cable hook	1
99	A26800700801	flat washer	2

PM 5160 SEHW-DYM1678D-3 spare parts list

Model : PM 5160 SEHW-DYM1678D-3
 update : 16.12.2017



Open embedded file for an exploded view.

Nr.	part no.	part description	quantity
100	A26800800303	spring washer	1
101	A26800501603A	lid nut	5
102	2106800361A	flameout cord ass'y	1
103	2106800427B	driving cord ass'y	1
104	21061000043201A	cord fixing board	1
105	A26800105602	self-driving screw	6
106	A26809009001	fixed pin	2
107	2109800108B	panel cover spring	2
108	21061002180001A	panel cover	1
109	21041003410001A	cover plate	1
110	A26800104601A	self-driving screw	6
111	2106200223A	throttle cross plate	1
112	21061001113201N	wave washer	4
113	21061003500001C	handle panel	1
114	21041003230001A	drink holder	1
115	21061001120001N	adjustment handle	1
116	A26800202501	tooth screw	1
117	A26800700301	big washer	1
118	2106200221B	choke pulling pole	1
119	21061004503201N	choke gear board	1
120	A26800604501	hexagon bolt	1
121	2106800176A	choke cord ass'y	1
122	2109900017A	battery	1
123	2011400058N	switch assembly	1
124	2108900025A	DC socket assembly	1
125	2100X02606	inner wire assembly	1
126	2108900037N	Wire Connector	2
127	A26800611401	screw	2
128	21061004573201N	outside positioned support	2
129	21061004593201N	inside positioned support	2
130	21061001803201B	self-propelled cord hanging block	4
131	21061001153206N	cover board of pulling pole support	2
132	21062006680001A	upper handle	1

PM 5160 SEHW-DYM1678D-3 spare parts list

Model : PM 5160 SEHW-DYM1678D-3
 update : 16.12.2017



Open embedded file for an exploded view.

Nr.	part no.	part description	quantity
133	21062001990104A	flameout pole	1
134	21062002080001A	driving pole	1
135	2106600017N	handle sheath	1
136	21071000050001N	handle of grass catcher	1
137	21071000073208B	grass catcher cover	1
138	2100X00693	rear cover board assy	1
139	21071000080103A	level indicator	1
140	A26800103202	self-driving screw	2
141	2107200071A	grass catcher bracket	1
142	21077000462133A	grass catcher	1
143	2011100217B	Plug cable	1
144	2269900004A	bellows	1,04 m
145	2012200002A	wrench	1
146	2012100004A	wrench pole	1
147	2070100046A	charger	1
148	A26800707001	flat washer	3
149	20342000160103N	guard	1
150	21031000230176D	wash port	1
151	2109100013N	O-rings	1
152	A26800100701	self-driving screw	2
153	21041004380001A	switch sheath	1
154	2109800149A	spring	1
155	21041004370001A	spring shield	1
156	21011002150001A	connecting shield	1
157	21041004360001A	button shield	1
158	21061002740103A	shift knob	1
159	A26800103502	self-driving screw	2
160	2011300020A	female terminal	2
161	2013900143	Nylon cable ties	2

PM 5160 SEHW-DYM1678D-3 spare parts list

Model : PM 5160 SEHW-DYM1678D-3
 update : 16.12.2017



T:\Daye Europe\
 Mowox\exploded
 view drawings

Open embedded file for an exploded view.

Nr.	part no.	part description	quantity
162	2103200233A	locking block B	1
163	2103800011A	torsional spring	1
164	2103300040A	stationary shaft	1
165	3043301003	split washer	1